

## Technical Specifications

<b>Power supply</b>	9 ... 28VDC
<b>Power consumption</b>	max. 60mW
<b>Interface</b>	RS232: for integration of RS232 devices max. 15m wire length adjustable baud rate & parity  Loxone Link: connection with Miniserver
<b>Power loss at max. load</b>	60mW
<b>Ambient temperature</b>	-40 ... 70°C / -40 ... 158°F
<b>Humidity</b>	max. 95% r. H. (non condensing)
<b>Safety rating</b>	IP20
<b>Dimensions</b>	35.5x88x57mm / 1.4x3.46x2.24" (LxWxH)
<b>Maintenance &amp; Cleaning</b>	This device is free of maintenance and may only be cleaned with a dry cloth.

## RS232 interface

<b>Wire cross-section</b>	0. ... .5mm <sup>2</sup> / AWG2 ...
<b>Stripping length</b>	mm / 0. "
<b>Temperature resistance</b>	-40 ... 70 °C / -40 ... 158°F

# LOXONE

## Need Help?

[loxone.com/support](https://loxone.com/support)

**Loxone Electronics GmbH**  
Smart Home 1  
4154 Kollerschlag  
Austria

[loxone.com](https://loxone.com)

V270420



# LOXONE

## RS232 Extension

Part No: 100013

## About the product

The Loxone RS232 Extension is a device for automatic control and management of home automation and similar non safety critical applications.

## Installation & electrical connection

The installation of the devices has to be mounted on a DIN rail in an electrical distribution housing (Standard distribution) and may only be performed by qualified personnel.

Protection against electrical contact and fire protection must be provided in the final installation by the use of a standards compliant/approved housing.

To turn the unit on/off during installation and in case of failure, a separator (disconnecting device) must be present. These must be easily accessible and visible. If the unit is used in a non conform manner as specified by the manufacturer the product included safeguards will be impaired.

## Power Supply and Link Connection

Wire cross-section	0.25 ... 0.8mm <sup>2</sup> / AWG23 ... 18
Stripping length	5mm / 0.2"
Temperature resistance	-40 ... 105°C / -40 ... 221°F

This folder is a part of the product!



For additional information, declaration of conformity, visit [www.loxone.com/help/rs232](http://www.loxone.com/help/rs232)

